


31 March 2011



Acoustic Sounder

Parts List

- 1 x LED
- 1 x PIC 16F88 (18 pin plastic DIP)
- 1 x 18 pin socket
- 2 x 10kΩ
- 1 x 1kΩ trimmer potentiometer
- 1 x 2N3904 transistor
- 1 x Speaker
- 1 x 7805 voltage regulator
- 1 x 10μF capacitor
- 1 x Battery connector
- 1 x Board
- 1 x SPST toggle switch
- 2 x RCA sockets